



## Instruction Manual

### Braided Teflon Hose Assembly Tool

#### PFETEFTL

**WARNING:** PLEASE READ ALL INSTRUCTIONS BEFORE PROCEEDING. PROFLOW WILL NOT BE RESPONSIBLE FOR ANY DAMAGE AS A RESULT OF THE INCORRECT USE OF THIS PRODUCT.

Included Items	QTY
Braided Teflon Hose Assembly Tool	1

Proflow's hand-held teflon hose assembly tool is designed to separate the stainless steel braid from the PTFE inner liner of our 200 series hose, making the insertion of the olive from the fitting a clean and simple process. It can be used with hose sizes from AN3 to AN8 as the tool has a stainless insert for varying hose size.

1. Identify which end of the stainless insert is needed depending on the size of your hose (Range from AN3-AN8).
2. Insert the stainless steel insert into the handle so the correct end needed is outwards away from the handle.
3. Cut your teflon hose using the appropriate cutting tool (PFECUT2) for a clean olive installation.
4. Grab the olive from your teflon fitting and slide it over the correct size insert on the tool.
5. Insert the end of the tool with the olive still on the insert into the teflon liner of your PTFE braided hose until the olive is fully seated. The teflon liner should sit flush with the edge on the inside of the olive.



**PROFLOW.COM.AU**

EMAIL: sales@proflow.com.au  
PHONE: 1300 879 879

#### PROFLOW LIMITED WARRANTY

This Proflow product is warranted to be free from defects in materials and workmanship for a period of one year from the original date of purchase. No warranty claim will be valid without authentic, dated proof of purchase. This warranty is to the original retail purchaser and none other and is available directly from Proflow and not through any point of distribution or purchase.